

# EDEN ROC GARAGE DOORS

CODING INSTRUCTIONS: ATA PTX5/PTX4/B&D TRIOCODE



---

## CODE LEARNING

---

**\*MAKE SURE YOUR GARAGE DOOR IS CLOSED\***

1. PRESS AND HOLD THE **BLUE DOOR CODE BUTTON** ON THE CONTROL PANEL
2. PRESS THE **TRANSMITTER BUTTON** YOU WOULD LIKE TO USE TO CONTROL THE DOOR FOR **2 SECONDS**
3. RELEASE AND PAUSE FOR **2 SECONDS**. PRESS THE SAME BUTTON AGAIN FOR **2 SECONDS**.
4. RELEASE THE TRANSMITTER BUTTON
5. PRESS THE TRANSMITTER BUTTON TO TEST THE OPERATION OF THE DOOR/GATE, ETC.

---

## CODE DELETING

---

1. **TURN OFF** THE OPENER
2. PRESS AND HOLD THE **BLUE DOOR CODE BUTTON**
3. **TURN ON** THE POWER AGAIN, **WHILE HOLDING THE BUTTON**. AFTER ABOUT **15 SECONDS**, THE CODING LED WILL ILLUMINATE TO INDICATE THAT THE RECEIVER'S MEMORY HAS BEEN DELETED
4. PRESS THE TRANSMITTER BUTTON TO TEST THAT THE TRANSMITTER NO LONGER WORKS – ALL CODES, INCLUDING THE COURTESY LIGHT CODES, ARE NOW WIPED.

