

EDEN ROC GARAGE DOORS

CODING INSTRUCTIONS: OLD STYLE AVANTI REMOTE



CODE LEARNING

MAKE SURE YOUR GARAGE DOOR IS CLOSED

1. OPEN THE WHITE LIGHT COVER ON THE OPENER ON THE CEILING OF YOUR GARAGE
2. QUICKLY PRESS AND RELEASE THE **RED LEARN BUTTON** – THE LED LIGHT WILL FLASH SLOWLY
3. SELECT WHICH BUTTON YOU WISH TO USE ON YOUR REMOTE AND QUICKLY PRESS AND RELEASE YOUR **SELECTED REMOTE BUTTON** – THE LED LIGHT WILL EXTINGUISH
4. QUICKLY PRESS AND RELEASE YOUR **SELECTED REMOTE BUTTON AGAIN** – THE LED LIGHT WILL FLASH QUICKLY
5. ON THE NEXT PRESS OF THE REMOTE THE GARAGE DOOR WILL OPEN.

TO CODE ADDITIONAL REMOTE, REPEAT STEPS 1 - 5

CODE DELETING

1. OPEN THE WHITE LIGHT COVER ON THE OPENER ON THE CEILING OF YOUR GARAGE
2. QUICKLY PRESS AND RELEASE THE **RED LEARN BUTTON** – THE LED LIGHT WILL FLASH SLOWLY
3. PRESS AND HOLD THE **BLACK RUN BUTTON** – THE LED LIGHT WILL FLASH QUICKLY
4. ALL REMOTE CODES WILL BE DELETED WHEN THE LED LIGHT STOPS FLASHING

WHEN CODES HAVE BEEN DELETED, REFER TO STEP 2 UNDER **CODE LEARNING** ABOVE TO RECODE REMOTES.

